



# Handling

## Thank you for purchasing an Aries CSP Socket!

While your socket was manufactured with the highest standards and excellent quality, care should be taken when handling your socket:

1. The socket should be stored “mounted”, using the supplied mounting screws, to either the supplied shipping plate or the test/BI board.
2. When the socket is not in use, the lid should be closed to prevent debris accumulation or damage to the exposed probe heads.
3. The bottom of the socket should NEVER be rubbed or scraped along any surface.
4. The socket should only be lifted vertically straight off the shipping plate and place vertically straight onto the test/BI board.
5. The center probe interposer must be handled by the edges only, and kept in the shipping box until ready to use.
6. NEVER rub/scrape the bottom of the interposer against any surface, or rub/scrape anything against the bottom surface of the interposer.

We appreciate your business and welcome any suggestions or comments. Please feel free to contact us via phone, fax or email.

Sincerely,

Quality Assurance  
Aries Electronics, Inc.